



LG-KPF34




LG-KPZ34



Keypads






LG-KPF43




LG-KPZ43




Keypads



LG-KPZ44




LG-KPF45



LG-KPF54



Keypads





3x4

	1	2	3	4	5	6	7	8	9	*	0	#
PIN	1	■	■	■								
	2				■	■	■					
	3							■	■	■		
	4									■	■	■
	5	■			■			■		■		
	6		■			■			■		■	
	7			■			■			■		■

4x3

	1	2	3	4	5	6	7	8	9	*	0	#
PIN	1	■			■		■					
	2		■			■			■			
	3			■			■			■		
	4									■	■	■
	5							■	■	■	■	
	6				■	■	■				■	
	7	■	■	■								

4x4

	1	2	3	A	4	5	6	B	7	8	9	C	*	0	#	D
PIN	1	■	■	■	■											
	2					■	■	■	■							
	3									■	■	■	■			
	4												■	■	■	■
	5	■					■			■				■		
	6		■					■			■				■	
	7			■				■				■				■
	8				■				■				■			

4x5

	A	B	F1	F2	→	9	6	3	#	←	8	5	2	*	Print	7	4	1	0	OK	
PIN	1	■	■	■	■	■															
	2						■	■	■	■	■										
	3											■	■	■	■	■					
	4																■	■	■	■	■
	5	■						■					■				■				
	6		■						■					■				■			
	7			■						■					■				■		
	8				■						■					■				■	
	9					■						■					■				■

5x4

	A	B	F1	F2	→	9	6	3	#	←	8	5	2	*	Print	7	4	1	0	OK	
PIN	1	■	■			■					■					■					
	2			■	■							■						■			
	3					■				■			■						■		
	4										■				■	■				■	■
	5																■	■	■	■	
	6												■	■	■	■					
	7						■	■	■	■											
	8	■		■							■										■
	9		■		■	■											■				